KING OF BOXER

SOLDER		PARTS	
1	GND	A	GND
2	GND	B	GND
3	DEFENSE 1	C	DEFENSE 2
4	SPEAKER	D	SPEAKER
5	+12V	E	+12V
6	-5V	F	-5V
7	UPPER 1	H	UPPER 2
8	+5V	J	+5V
9	+5V	K	+5V
10	UP 1	L	UP 2
11	DOWN 1	M	DOWN 2
12	START 2	N	SERVICE
13	START 1	P	COIN 1
14	RIGHT 1	R	STRAIGHT 1
15	LEFT 1	S	RED
16	BLUE	T	RIGHT 2
17	GREEN	U	LEFT 2
18	SYNC	V	STRAIGHT 2